



PARDUS

**BARREL BREAK
AIR RIFLE
INSTRUCTION MANUAL**

**READ THE INTRUCTIONS AND
WARNINGS IN THIS MANUAL CAREFULLY
BEFORE USING THIS FIREARM**

SAFETY FIRST

Please do not use your shotgun before reading safety rules and this manual.


Observe these rules of safe gun handling.

1. Always keep the muzzle pointed in a safe direction. Watch the muzzle at all time, never point a gun. accidentally or intentionally, at any person or anything you do not intend to shoot. Identify the target before shooting; do not shoot at sounds.
2. Always treat a gun as if it is loaded - it may be!
3. Keep your finger off the trigger while operating the action and at all other times until you are ready to shoot.
4. Keep the safety "on" or in the "safe" position at all times until you are ready to fire. Do not rely on your gun's safety, the safety on any gun is a mechanical device and is not intended as a substitute for common sense or safe gun handling.
5. Learn how your gun functions and handles. If you do not thoroughly understand the proper use and care of your gun, seek the advice of someone who is knowledgeable.
6. Do not alter or modify any part of the firearm.
7. Store guns unloaded, separate from any ammunition, and out of the reach of children.
8. Be sure the barrel is clear of any obstructions before loading. Make it a habit to check the barrel every time before loading.
9. Be sure you have and use the proper ammunition. Please read the caliber information on your air rifle accordingly choose the correct pellet; 4,5mm (.177") or 5,5mm (.22") or 6,35mm (.25").
10. Wear protective shooting glasses and adequate ear protection when shooting.
11. Never climb or jump over anything, such as a tree, fence, or ditch, with a loaded gun. Put safety ON. Open the barrel on barrel break shotguns, remove the shells/discharge the chamber on pump and semi-auto shotguns and hand the gun to someone else or place it on the ground on the other side of the obstacle before crossing it yourself. Do not lean a gun against a tree or other object; it could fall and possibly discharge.
12. Do not shoot at a hard surface or at water. Bullet and shot can ricochet or bounce off and travel in unpredictable directions with great velocity.
13. Never transport a loaded gun. DO NOT place a loaded gun into a vehicle. The gun should be unloaded and placed into a case when not in use.
14. Never drink alcoholic beverages before or during shooting.
15. Never try to repair the shotgun on your own if you are not educated or expert of. This may cause un-willed damage to your gun which may seriously injure you or someone around you.
16. Never fire your gun without choke tubes (if comes with interchangeable choke tubes and a thread in the muzzle) snugly tightened in barrels.




1. Punto de mira/Foresight/Guidon/Korn/Ponto de mira
2. Boca de canon/Muzzle/Bouche du canon/Rohrmündung/Entrada do cano
3. Canon/Barrel/Canon/Lauf/Cano
4. Alza/Rear sight/Hausse/Visier/Alça
5. Seguro Manual/Manual safety/Surete manuelle/Manuelle sicherung/Segurança
6. Gatilho regulable/Two-stage trigger/Detente reglable/Regulierbarer abzugshebel/Gatilho/Grillete a due tempi
7. Tornillo de regulacion/Trigger adjustment screw/Vis de reglage/Regulierschraube/Parafuso de Regulação (*)
8. Empunadura/Grip/Poignee/Griff/Empunhadure/Impugnatura
9. Culatrín/Buttplate/Plaque de couche/Schulterstütze/Chapa de couce
10. Carrillera/Cheekpiece/Piece de jouce/Backenauflage/Camara
11. Culata/Stock/Crosse/Gewehrkolben/Coronha
12. Adaptador de visor/Scope rail/Adaptateur de viseur/Visieradapter/Adaptador do visor/Silitta per il cannocchiale

(*) Segun modelo/Accordig to model/selon modele/Ie nach Modell/Mediante o Modelø



⑤ Correct shot
Disparo correcto
Tir correct
Richtiger Schuss
Disparo correcto
Tiro Corretto

⑥ Incorrect shot
Disparo incorrecto
Tir incorrect
Unrichtiger Schuss
Disparo incorrecto
Tiro non corretto



INTRODUCTION

Before you use your new PARDUS AIR RIFLE you must read and understand the following safety rules:

WARNING: This is not a toy. Failure to follow the safety rules outlined bellow can result in serious bodily injury or death.

CAUTION: This product is not recommended for unsupervised use by those under 16 years of age.

CAUTION: This product is designed to handle and function like a air gun. Do not carry or use this product in any situation where it might be mistaken for a firearm.

OPERATION OF THE SAFETY

WARNING: There is no substitute for muzzle control. Never rely on any mechanical safety. Always point the gun in a safe direction.

The safety catch is located in front of the trigger (see fig. B-3). The safety is on when the lever is in the rear position (near the trigger). To release the trigger, move the lever to the forward position (away from the trigger).

WARNING: Always put the safety "ON" when handling, carrying, loading or unloading the air gun.

CAUTION: Do not press the trigger while putting the safety "ON"

TRIGGER ADJUSTMENT

WARNING: Be sure the air gun is not loaded before adjusting trigger

WARNING: There is no substitute for muzzle control. Never rely on any mechanical safety. Always point the gun in a safe direction.

This gun is supplied with a trigger with an adjusting screw for second stage length (see fig. C-4). Adjustment is carried out as follows: for reduction - rotate screw clockwise, for increase-rotate screw counter-clockwise.

WARNING: Always put the safety "ON" when handling, carrying, loading or unloading the air gun.

LOADING

WARNING: Before loading or firing your air gun for the first time, pass a cleaning rod through the bore to make sure it is free of obstructions.

WARNING: Always put the safety "ON" when handling, carrying, loading or unloading the air gun.

WARNING: Release the barrel and pull it downwards and towards to you until it is completely cocked. Insert the pellet, always with the skirt to the rear, until it is completely inserted into the chamber (Photo 1)Then return the barrel original position (Photo 2).

Care about the position of manual safety switch.

When manual safety switch is ON (Photo 3), trigger can not be pulled. When you are ready to shoot, turn it to OFF position (Photo 4)

WARNING: Remember that the gun is loaded and the pellet is in position to fire.

WARNING: Always return the loading lever to its original position before firing a shot, otherwise the rifle will not work properly and might cause damage or injury.

FIRING

WARNING: Always put the safety "ON" when handling, carrying, loading or unloading the air gun.

CAUTION: Keep your finger away from the trigger until you are ready to fire To fire your air gun, aim at your target, release the safety, and gently squeeze the trigger.

WARNING: If a pellet becomes lodged inside the barrel, refer to the "PROCEDURE FOR CLEARING STUCK AMMUNITION" section.

WARNING: Each time the air gun is to be put away after use, please ensure that the last round has been fired, that the magazine is completely empty, and that the air gun is not longer cocked. This will prevent the possibility of accidents occurring when the air gun is used again.

PROCEDURE FOR CLEARING STUCK AMMUNITION

WARNING: Do not touch face or mouth after handling pellets. Wash hands after handling pellets.

WARNING: NEVER attempt to clear stuck ammunition by firing an additional pellet through the gun.

CAUTION: Be sure that the safety catch is «ON» prior to clearing an obstruction.

Pull on the loading lever until it clicks and return it to its original position. Open the rotating loading chamber by turning it in an anti-clockwise direction as far as it will go. Return the loading lever to the closed position parallel to the barrel. Insert a cleaning rod suitable for the calibre of your weapon (4.5mm or 5.5mm) via the muzzle of the barrel and push until the barrel is free of ammunition. If a pellet had been jammed in the barrel, it is now likely to be located in the rotating loading chamber.

Then clean the barrel with the ramrod brush to remove any lead particles that may have become stuck to the rifling.

NOTE: Always discard defective or deformed ammunition.

WARNING: Each time the air gun is to be put away after use, please ensure that the last round has been fired, that the magazine is completely empty, and that the air gun is not longer cocked. This will prevent the possibility of accidents occurring when the air gun is used again.

CAUTION: When you are ready to put your gun away, with the barrel pointed toward the floor, make sure that there is no ammunition in the barrel. This way you will prevent any possible accident the next time you use your gun.

SIGHT PICTURE AND ADJUSTMENT

The PARDUS AIR RIFLE has a rear sight which is adjustable for windage (right-left) and elevation (up-down). The sights are "open" sights. The rear sight is a notch. The front sight is a post. The sight picture should look like the examples (fig. D).

Windage adjustment

If the shot is deflected to the left of the target, turn the screw 1 (fig. A) clockwise. If the shot deflected to the right of the target, turn the screw counter-clockwise.

Elevation adjustment

If the shot is too high, turn the screw 2 (fig. A) clockwise. If the shot is too low, turn the screw counter-clockwise.

STORAGE

WARNING: Airguns should be stored in such a manner to protect against unauthorized use by children.

WARNING: These products are designed to look, handle and function like rifles. These products should be stored in such a manner to protect against theft and subsequent misuse.

CAUTION: When storing your rifle, always make sure it is unloaded and the safety in "ON".

CLEANING

WARNING: Make certain the rifle is unloaded and the safety in "ON" before cleaning.

To clean the rifle barrel, always open the barrel in the same way as when loading it. Use the appropriate calibre cleaning rod, rod tip patches, and bore brush with gun solvent and oil to clean your rifle. Insert the cleaning rod with cleaning attachment from the muzzle. Remember you should never use lubricating oil in the barrel. NEVER apply oil to the breech or into the cylinder. You should also clean the outside metal parts with oil to prevent them from rusting.

DANGER: NEVER put any oil inside the barrel or the chamber. The resulting combustion could cause irreparable damage to your rifle and seriously harm to you and other people.



WARRANTY AND AFTER SALES SERVICE

Pardus agrees to service its products thru your country importer free of charge for defects in materials and workmanship in accordance with the service agreement listed below.

The obligation of **Pardus** under this agreement is limited to the repair or replacement of unserviceable parts and does not cover any incidental or consequential damages. Other than the express warranty contained herein **Pardus** makes no warranties, express or implied.

Pardus will repair or replace any unserviceable part(s) for one (1) year from date of purchase in accordance with the above warranty statement provided your product had not been altered, abused, willfully damaged, or damaged by overpressure ammunition. And further guarantees to supply parts with its cost for following additional 5 years.

This agreement is not transferable; its benefits apply only to the original purchaser. To obtain free service during the time this agreement is in effect, make sure your product is unloaded, and send it to your **Country Importer**. If you do not know the importer and would like us to track for you, please provide us your country information and the serial number of your gun. This agreement and the warranties contained herein are void if you are not the licenced owner of the gun.



PARDUS SAVUNMA VE AV SANAYİ İTHALAT VE İHRACAT LTD. STİ.

Dudullu OSB, İmes San. Sitesi B Blok 205. Sk. No.22

Ümraniye 34776 - İstanbul / TÜRKİYE

P: +90 216 642 2353 PBX • F: +90 216 642 2360

www.pardusarms.com

pardusarms@pardusarms.com